


MBF 1832 HOBBY

EXPLODED VIEW DRAWING



PARTS LIST

Refer to the Exploded View Drawing for the location of parts listed below

ITEM	DESCRIPTION	ITEM	DESCRIPTION
1	SCREW	39	TRIGGER VALVE STEM
2	BUSHING	40	TRIGGER VALVE GUIDER
3	EXHAUST COVER	41	TRIGGER SPRING
4	WASHER	42	PIN
5	SCREW	43	RAIL
6	CYLINDER CAP	44	PIN
7	SEAL	45	TRIGGER
8	O-RING 53×1.5	46	WASHER
9	O-RING 50.5×2.5	47	PLATE
10	SPRING	48	SCREW
11	O-RING 15×1.9	49	FRONT PLATE
12	O-RING 38.3×3	50	LATCH ASSEMBLY
13	VALVE	51	PIN
14	O-RING 33.5×3.5	52	PIN
15	O-RING 22.5×2.8	53	SCREW
16	O-RING 28.3×3	54	GUIDE BODY
17	PISTON ASSEMBLY	55	PIN
18	O-RING 48.5×2.5	56	MOVABLE MAGAZING UNIT
19	COLLAR	57	SPRING
20	O-RING 27.3×2	58	LOCK
21	O-RING 35.6×1.8	59	LOCKING WASHER
22	CYLINDER	60	PIN
23	BUMPER	61	FEEDER SHOE
24	BODY	62	SPRING
25	JOINT GUIDER	63	SPRING RETAINER
26	SAFE GUIDER	64	STOPPED PIECE
27	SPRING	65	STOPPED PLATE
28	SAFE BRACKET A	66	SCREW
29	SAFE BRACKET B	67	FIXED MAGAZINE UNIT
30	SAFE BRACKET C	68	SCREW
31	SCREW	69	SUPPORT
32	PIN	70	NUT
33	O-RING 10.3×1.9	71	SCREW
34	TRIGGER VALVE HEAD	72	SOFT GRIP SLEEVE
35	SPRING	73	O-RING 40.2×2.3
36	O-RING 6.3×1.25	74	END CAP
37	O-RING 8.3×1.8	75	AIR PLUG
38	O-RING 6.4×1.5		